

| No | Name            | Note  |
|----|-----------------|---|
| 1  | RS-232C_TXD     | -   |
| 2  | RS-232C_RXD     | -   |
| 3  | GO (Signal GND) | -   |
| 4  | RS-485_DB(+)    | -   |
| 5  | RS-485_DA(-)    | -   |
| 6  | GO (Signal GND) | GO is internally connected with Terminal No.3.                                      |
| 7  | RS-485_DB(+)    | RS-485_DB (+) is internally connected with Terminal No.4.                           |
| 8  | RS-485_DA(-)    | RS-485_DA (-) is internally connected with Terminal No.5.                           |
| 9  | RS-485_END1     | When using RS-485 and termination is required, Terminal No.9, and 10 are connected. |
| 10 | RS-485_END2     | When using RS-485 and termination is required, Terminal No.9, and 10 are connected. |

